

CeraClean® 590+

DESCRIPTION

Cleaning roller final soaking solution for photopolymer plates, suitable for use in post-print washout units with all types of inks, eliminating the need for a final water rinse.

CHARACTERISTICS	
Appearance	straw-colored liquid
Density 20°C, g/cm ³	1,00 ± 0,03
pH	10,0 ± 1,0
TBoiling point	undefined
Flash-point	undefined
Solubility	soluble in water
Packaging	canister 25l

APPLICATION

CeraClean® 590+ is intended for daily use in automatic washing devices, with a particular emphasis on its effectiveness in Polymount washout units.

METHOD OF USE

Pour the ready-made solution into the designated tank in the washing device and subject the photopolymer plates to the appropriate cleaning cycle.

While using highly effective industrial cleaning agents, it is essential to observe special precautions and adhere to occupational health and safety regulations. During application, required personal protective equipment should be worn, and after completion, hands and work materials should be thoroughly washed. The product should only be stored in its original packaging, which, when emptied, must be disposed of in accordance with the instructions provided in the safety data sheet. Familiarize yourself with the hazards and safety guidelines on the label and safety data sheet, available upon request or on our website.