

CeraClean® W 11

PRODUCT DESCRIPTION

CeraClean® W 11 is a specially formulated product for the manual deep cleaning of anilox rollers from the remains of water-based inks and varnishes. It does not attack aluminium.

TECHNICAL DATA

Appearance	colorless, viscous liquid
Relative density in 20°C, g/cm ³	1,05
pH	12,55 (20°C)
Boiling point	100°C (start)
Flammability	non-inflammable
Solubility	soluble in water
Package	bottle 750ml

APPLICATION

CeraClean® W 11 is used for periodic washing of the anilox rollers.

INTENDED USE

The product will be applied with a tuft and worked in with a stainless steel brush. After a soaking time of 5 – 10 minutes the anilox roller should be rinsed with a high pressure cleaner. Take precautions, not to be too close on the surface with the high pressure nozzle.

Attention: Please, make sure that the paste does not remain for too long on the roller and dries. In such a case the ink residues and dirt stay in the cells.

When using highly effective cleaning agents for industrial applications, special precautions must be taken, and health and safety regulations must be followed. The required personal protective equipment should be used during application, and after completion, hands and work materials should be thoroughly washed. The product should only be stored in its original packaging, which must be disposed of according to the instructions on the safety data sheet after it is emptied. Familiarize yourself with the hazards and safety rules on the label and the safety data sheet, which is available upon request.